ON/OFF

Set Up
Run
Low Voltage
Group Remote Control
Set Up
Confirm
Screen Off
Up
Down
A
Match Code
B
1
2
3
4
5
6
7
8
9
0
C
D
2.Press “Screen Off”
1.Switch On
3.Switch Off

MATCH CODE

2.Press “Set Up”

4.Press “ Confirm”

5.When the parking lock is power on,
Long-press “Match Code” about three seconds.
If it is successful, the light of parking lock will be on.

3.Press the Number Keypad to set up
the code number. Example: 001

1.Switch On

UP/DOWN

Set Up
Run
Low Voltage
Group Remote Control
Set Up
Confirm
Screen Off
Up
Down
A
Match Code
B
1
2
3
4
5
6
7
8
9
0
C
D
2.Press “Set Up”
4.Press “ Confirm”
5.Press “UP” or “ Down”
3.Press the Number Keypad to enter the code number
1.Switch On